

VORTEX BREAKER INSTALLATION INSTRUCTIONS

For Use With: Any OMG Hercules[®] Retrofit Roof Drain with either a clamp ring or coated flanges.

**For technical assistance
contact OMG at 800-633-3800.**

HERCULES CLAMP RING MODEL

- STEP 1** Using a #2 square drive screwdriver, back-out the three fasteners securing the existing strainer to the clamp ring. Discard strainer and fasteners.
- An OlyFlow screwdriver is a #2 drive.



- STEP 2** Line up the three fastener holes on the OMG Vortex Breaker Strainer with the holes on the clamp ring and secure with the fasteners provided using a #2 square drive screwdriver.



HERCULES COATED FLANGE MODEL

- STEP 1** Using needle nose pliers, remove the three nylon push-in fasteners attaching the existing strainer to the retaining clips. Discard strainer and removed fasteners.



- STEP 2** Line up and install the three slots on the OMG Vortex Breaker Strainer with the three retaining clips on the drain flange and insert the nylon push-in fasteners provided.

